



AB01



Astragal Bar Installation Instructions

The FoamLINK foam tape we supply is a PSA “pressure sensitive adhesive”, therefore when applying the Astragal Bars please make sure sufficient pressure is applied.

Please ensure that the surfaces the tape will be adhered to are clean from all dirt and dust by using an isopropanol cleaner. We don't supply the cleaner, but it can be purchased from UK Industrial Tapes - www.ukindustrialtapes.co.uk

Please note that if the bars are cut too tight to the frame this will cause stress on the adhesive tape bond, we then suggest to leave an approximate 1mm gap between the bar and the frame at each end of the bar this will allow for expansion and contraction of the surfaces.

We also recommend that once the windows & bars have been glazed up, protect the finish product from rain for at least 72 hours. All Acrylic adhesive systems take 72 hours to reach their optimum bond.